

Premium-Tannenbaum, dekoriert, 180cm
Premium pine tree, decorated, 180cm

No. 8350029A

DE. BEDIENUNGSANLEITUNG

Vielen Dank für den Kauf dieser Tannenbaums mit LED-Lichterkette, der für eine fröhliche Weihnachtsstimmung in Geschäften und auf der nächsten Weihnachtsparty. Durch die eingesetzten LEDs ist das Produkt extrem langlebig, energiesparend und entwickelt kaum Wärme.

SICHERHEITSHINWEISE

Bitte lesen Sie vor der Verwendung des Produkts diese Informationen. Sie erhalten dadurch wichtige Hinweise für den korrekten Betrieb. Bewahren Sie diese Anleitung für weiteren Gebrauch auf.

Verwendungszweck

- Dieses Produkt ist nicht für die Benutzung im Freien geeignet! Nur für den Innenbereich! Nicht in der Nähe von Wasser oder Hitzequellen verwenden! Der ideale Temperaturbereich liegt bei -5 bis +45 °C.
- Verwenden Sie das Produkt ausschließlich gemäß den hier gegebenen Vorgaben. Bei Schäden, die durch Nichtbeachten dieser Anleitung verursacht werden, erlischt der Garantieanspruch. Für Folgeschäden wird keine Haftung übernommen.
- Bei Sach- oder Personenschäden, die durch unsachgemäße Handhabung oder Nichtbeachten der Sicherheitshinweise verursacht werden, übernehmen wir keine Haftung und es erlischt jeder Garantieanspruch.
- Aus Sicherheitsgründen ist das eigenmächtige Umbauen oder Verändern des Produkts nicht gestattet und hat den Verfall der Garantieleistung zur Folge.

Gefahr durch Elektrizität

- Das Produkt wird mit lebensgefährlicher Netzspannung versorgt. Um Stromschläge zu vermeiden, niemals irgendeinen Teil des Produkts öffnen. Nur an eine vorschriftsmäßige Steckdose anschließen, die der Produktspezifikation entspricht.
- Dieses Produkt darf nicht mit anderen Lichterketten o. Ä. elektrisch verbunden werden.
- Dieses Produkt darf nur mit dem beiliegenden Netzadapter verwendet werden.
- Die Reinigung beschränkt sich auf die Oberfläche. Dabei darf keine Feuchtigkeit in Anschlussräume oder an Netzspannung führende Teile gelangen. Wischen Sie das Produkt nur mit einem trockenen, fusselreifen Tuch ab. Zuvor den Netzstecker aus der Steckdose ziehen.
- Wenn das Produkt nicht mehr ordnungsgemäß funktioniert oder Schäden aufweist, nehmen Sie es bitte außer Betrieb und kontaktieren Ihren Fachhändler. Niemals selbst Reparaturen durchführen.

Gefahr für Kinder

Das Produkt ist kein Spielzeug. Halten Sie es vor Kindern und Haustieren fern. Lassen Sie Verpackungsmaterial nicht achtlos liegen.

Warnung vor Verletzungen

- Die verwendeten LEDs sind fest verbaut und können nicht ausgetauscht werden.
- Achtung, LED-Licht: Schauen Sie nicht für längere Zeit direkt in die Lichtquelle.
- Gehen Sie vorsichtig mit dem Produkt um. Durch Stöße, Schläge oder dem Fall aus bereits geringer Höhe wird es beschädigt.
- Verlegen Sie das Anschlusskabel so, dass es nicht zur Stolperfalle wird.

Umweltschutz

 Übergeben Sie das Produkt am Ende der Nutzungsdauer zur umweltgerechten Entsorgung einem örtlichen Recyclingbetrieb. Geräte, die mit diesem Symbol gekennzeichnet sind, dürfen nicht im Hausmüll entsorgt werden. Für weitere Informationen wenden Sie sich bitte an Ihren Händler oder die zuständige örtliche Behörde.

INBETRIEBNAHME

Stellen Sie den Tannenbaum am gewünschten Ort auf. Verbinden Sie die Steckverbindungen der Lichtkette miteinander (auf richtige Polung der Verbindungsstecker achten). Schließen Sie die Lichtkette über das Netzteil an den Strom an. Die LEDs leuchten. Zum Ausschalten ziehen Sie den jeweiligen Netzadapter aus der Steckdose. Wird das Produkt längere Zeit nicht benötigt, den Netzadapter aus der Steckdose ziehen, um unnötigen Stromverbrauch zu vermeiden.

TECHNISCHE DATEN

Spannungsversorgung:230 V AC, 50 Hz über mitgeliefertes Netzteil (31 V DC)
Gesamtanschlusswert:4 W
Anzahl der LEDs:300
Höhe:180 cm
Gewicht:8,5 kg

Änderungen vorbehalten.



EN. USER MANUAL

Thank you for purchasing this Christmas tree with LED light chain, which is the perfect way to create a jolly Christmas mood in shops and at the next Christmas party. This product is fitted with LEDs that consume little power, have an extremely long service life and develop little heat.

SAFETY WARNINGS

Please read these instructions carefully before using the product. They contain important information for the correct use of your product. Please keep them for future reference.

Intended use

- This product is not an outdoor product! Only for indoor use! Do not use this device near water or heat sources. The recommended temperature range is -5 to +45 °C.
- Only use the product according to the instructions given herein. Damages due to failure to follow these operating instructions will void the warranty! We do not assume any liability for any resulting damage.
- We do not assume any liability for material and personal damage caused by improper use or non-compliance with the safety instructions. In such cases, the warranty/guarantee will be null and void.
- Unauthorized rebuilds or modifications of the product are not permitted for reasons of safety and render the warranty invalid.

Danger due to electricity

- The product is supplied with hazardous mains voltage. To reduce the risk of electric shock, do not open any part of the product. Only connect the product to a proper wall socket that complies with the product specification voltage.
- The product must not be electrically connected to other light chains or anything similar.
- The product must be used only with the supplied power adapter.
- Cleaning of the product is limited to the surface. Make sure that moisture does not come into contact with any areas of the terminal connections or mains voltage control parts. Only wipe off the product with a dry, lint-free cloth. Before cleaning, disconnect the product from the mains.
- If this product is no longer working properly or is visibly damaged, take it out of operation and consult your local dealer. Do not attempt to repair the product yourself.


Danger to children

This product is not a toy. Keep it out of the reach of children and pets. Do not leave packaging material lying around carelessly.

Warning - risk of injuries

- The built-in LEDs are permanently installed; they cannot be replaced.
- Caution, LED light: Do not look directly at the light source for long periods.
- Handle the product with care, it can be damaged by impacts, blows, or accidental falls, even from a low height.
- Run the mains cable in such a way that it cannot be tripped over.

Protecting the environment

 When to be definitively put out of operation, take the product to a local recycling plant for a disposal which is not harmful to the environment. Devices marked with this symbol must not be disposed of as household waste. Contact your retailer or local authorities for more information.

OPERATION

Install the tree at the desired location. Connect the lighting chain (observe polarity of connecting pins). Connect the chain to the mains via the power supply unit. The LEDs light up.

To switch off, unplug the power adapter from the socket. If the product is not used for a longer period, disconnect the adapter from the mains socket, to prevent unnecessary power consumption.

TECHNICAL SPECIFICATIONS

Power supply:230 V AC, 50 Hz via included power unit (31 V DC)
Power consumption:4 W
Number of LEDs:300
Height:180 cm
Weight:8.5 kg

Subject to change.